



Plastic Knob Instructions

- 1) Heat water to 120 degrees F and immerse knob in water for 1-2 minutes or until plastic is slightly softened.
- 2) Firmly press knob onto receptacle.

NOTE: Knob should be lined up as desired **BEFORE** it is pressed onto shaft.