



INST# 56

To use the enclosed dual filament bulbs you will need to convert your sockets by installing contacts, insulators and the wires out of the assemblies we sent.

Remove wires with contacts and insulators from all four socket assemblies.

File grooves in the very bottom of your original socket that are 180 degrees from pins on bulb when the bulb is in the **locked position**. This is to allow the oval base on the new insulators to slide through the grooves you filed indexing the new contacts to your socket. **Indexing the bulb contacts to the socket contacts is critical!**

Before filing grooves in the bottom of your original socket, if the directions are not clear-carefully study the relationship of contacts in the new contacts you received from us to the position of bulb pins when bulb is **locked in place**