



- | | | | | | |
|-----------|---|--------------------------|--------|---|--------------------|
| Black | 1 | Right rear flasher lamp | Orange | 5 | Stop Switch |
| Sky Blue | 2 | Right front flasher lamp | Red | 6 | Flasher L terminal |
| Dark Blue | 3 | Left rear flasher lamp | Yellow | 7 | Flasher P terminal |
| Green | 4 | Left front flasher lamp | | | |

as each cord can be distinguished by color, the wiring should be made according to the above drawing
 * Notice: Cam is not needed to install for non-cancelling Switch.

INS985720E